




FLEXIBORE

INSTRUCTIONS FOR FITTING THE POWER CABLE




1. Preparation

Thread the strap under each loop on the strip along the hose length. Maximum 2m intervals.


2. Securing the power cable

Ensure that the power cable is secured firmly to the strap using a clove-hitch knot shown.




3. Tightening the power cable

The power cable should not be able to slip through the knot so pull it up tightly.




4. Buckle position

Keep the buckle on the same side as the power cable to prevent it being crushed when going over the installation roller.



5. Snake the cable to allow for stretch

Allow approx 5% slack in the power cable to compensate for the stretch in the hose due to the weight of the pump and water etc. (Refer to manual)



Securing the cable correctly to the hose makes for trouble-free pumping.



Further information can be obtained from our web site
www.crusaderhose.com.au or call 03 9720 1100